

SERVICE & WARRANTY INFORMATION

HOW TO GET SERVICE UNDER THE TERMS OF THE LIMITED ONE YEAR WARRANTY

For warranty repair, do not return your product to the place of purchase. Instead, follow the instructions below to obtain warranty service as our dealer network is not prepared to service the product under the terms of this warranty.

1. First, write, call, email or FAX MTH Electric Trains, 7020 Columbia Gateway Drive, Columbia, MD 21046, 410-381-2580 (FAX No. 410-423-0009), or on the internet at service@mth-railking.com or our web site, www.mthtrains.com, stating which product you have, when it was purchased and what seems to be the problem. You will be given a return authorization number to assure that your merchandise will be properly handled upon its receipt at MTH.

2. CAUTION: Make sure the product is packed in its original factory packaging including its foam and plastic wrapping material so as to prevent damage to the merchandise. The shipment must be prepaid and we recommend that it be insured. A cover letter, including your name, address, daytime phone number, a copy of your sales receipt, the Return Authorization number and a full description of the problem, must be included to facilitate the repairs. Please include the description regardless of whether or not you discussed the problem with one of our service technicians when contacting MTH for your Return Authorization number.

3. Please make sure you have followed the instructions carefully before returning any merchandise for service.

LIMITED ONE YEAR WARRANTY

This item is warranted for one year from the date of purchase against defects in material or workmanship. We will repair or replace (at our option) the defective part without charge for parts or labor, if the item is returned to the address below within one year of the original date of purchase. This warranty does not cover, light bulbs, traction tires or items that have been abused or damaged by careless handling. Transportation costs incurred by the customer are not covered under this warranty.



This warranty gives you specific legal rights and you may have other rights which vary from state to state.



M.T.H.

ELECTRIC TRAINS, INC.

7020 COLUMBIA GATEWAY DRIVE
COLUMBIA, MD 21046-1532



The M.T.H. Jordan Spreader adds heavy duty snow plowing and clearing power to your layout. Constructed from sturdy ABS plastic and brightly painted, the Jordan Spreader is a perfect addition to any O Gauge layout.

The M.T.H. Jordan Spreader is pre-assembled, so there is no setup. Operation and maintenance is made easy by reading and following the instructions on the following pages.

JORDAN SPREADER

OPERATING INSTRUCTIONS

Although fully assembled (photo 1), there are a few procedures to install options and for maintenance. Photos 2 and 3 show the simple steps needed to change the two light bulbs inside the cab. First remove the roof by pulling upward. Refer to photo 2. Be very careful of the circuit board which may be **HOT TO THE TOUCH!** Before you change any light bulb, it is recommended that you let the model cool off after running. The interior light is a press fit. Pull upward on the interior light bulb to remove (photo 3). The headlight is attached to a connector. Lift up the wire attached to the connector and unplug (photo 3). Reinsert the connector of the new headlight. To install the optional coupler cover, unscrew and remove the coupler as shown in photos 4 and 5. Now insert the coupler cover into the opening with the tabs facing in towards the plow. Snap the coupler cover in place. See photo 6&7. The spreaders are opened (photo 8) by simply pulling them outward until the locking bar is locked into place against the plastic support (photo 9). To retract the spreaders, push in the direction of the arrow on the locking bar as seen in photo 9. Be careful as the spreaders are under spring tension.

